DENON

プリセットコード一覧表 / List of Preset Codes / Liste von voreingestellten Codes / Liste des codes pré-réglés / Lista dei codici pre-regolati / Lista de Códigos Pre-ajustados / Lijst van vooringestelde codes / Förteckning över förinställda koder / 預選代碼一覽表 / 预选代码一览表

ケーブルのセットアップコード SETUP CODES FOR CABLE SETUP-CODES FÜR KABEL CODES DE REGLAGE POUR CABLE REGOLAZIONE CODICI PER CAVI AJUSTAR CÓDIGOS PARA CABLE INSTELCODES VOOR KABEL INSTÄLLNINGSKODER FÖR KABEL-TV-MOTTAGARE 線纜設置代碼 线缆设置代码

纹 规 反
ABC
B Bell South
C Cable & Wireless 1095
D Daeryung
F Filmnet
G General Instrument 0503, 0837, 0303, 0030 GoldStar
H Hamlin
J Jerrold0503, 0837, 0303, 0030
L LG 0171
MNet

N NTL	
O	.1095
P PVP Stereo Visual Matrix	.0264, 1087, 1095 .0027, 0035, 0134 .0027 .0332, 0344 .0904, 1904, 0171, 0560
Q Quasar	.0027
Regal	
S Sagem	.0027, 0171 .0904, 1904, 0504, 0035 .1033 .0030
T TS. Tele+1 Telewest. Torx. Toshiba Trans PX.	.0470 .1095 .0030 .0027
U United Cable	.0030
Z Zenith	.0027, 0552, 0926

CDプレーヤーのセットアップコード	Meridian 0184
CD プレーヤーのセットアップコード SETUP CODES FOR CD PLAYERS	Micromega 0184
SETUP-CODES FÜR CD-PLAYER	Miro
	Mission
CODES DE REGLAGE POUR LECTEURS CD	Myryad
REGOLAZIONE CODICI PER LETTORE CD	111/1/400
AJUSTAR CÓDIGOS PARA LOS REPRODUCTORES DE CD	N
INSTELCODES VOOR CD-SPELERS	NAD
INSTÄLLNINGSKODER FÖR CD-SPELARE	NSM 0184
鐳射唱盤播放機設置代碼	Naim
镭射唱盘播放机设置代码	0
	Optimus
A	P
Aiwa 0184	-
Arcam	Panasonic 0056
Audio Research0184	Philips 0184
AudioTon0184	Pioneer
	Polk Audio 0184
Audiolab	Proton 0184
Audiomeca 0184	•
С	Q
Cairn	QED 0184
California Audio Labs 0056	Quad
	Quasar
Carver	R
Cyrus0184	
D	RCA
DKK	Realistic 0206
DMX Electronics 0184	Revox
Denon	Rotel 0184
Dynamic Bass 0206	S
Dynamic Bass 0200	SAE
E	Sansui
Emerson 0332	Sanyo
г	Scott
F	Sears
Fisher	
G	Sharp
Genexxa	Simaudio
Goodmans	Sonic Frontiers 0184
Grundig	Sony
Grandig	Symphonic 0332
Н	Т
Harman/Kardon 0184, 0200	TAG McLaren 0184
Hitachi	
	Tandy
J	
JVC 0099	Thorens
K	Thule 0184
Kenwood	U
	Universum 0184
Krell0184	
L	V
 LXI0332	Victor
Linn	w
M	Wards 0184
MCS 0056	
Magnavox 0184, 0332	
Marantz	
Mateui 0184	

カセットブレーヤーのセットアップコード SETUP CODES FOR CASSETTE PLAYERS SETUP-CODES FÜR CASSETTEN-PLAYER CODES DE REGLAGE POUR LECTEURS DE CASSETTE REGOLAZIONE CODICI PER RIPRODUTTORE A CASSETTE AJUSTAR CÓDIGOS PARA REPRODUCTORES DE CASSETTE INSTELCODES VOOR CASSETTESPELERS INSTÄLLNINGSKODER FÖR KASSETTBANDSPELARE 卡式録音座設置代碼 卡式录音座设置代码

A Aiwa
C
Carver
D Denon
G Grundig
H Harman/Kardon 0056
M Magnavox 0056 Marantz 0056 Myryad 0056
O Optimus
Philips 0056 Pioneer 0054 Polk Audio 0056
R RCA
S Sansui
T Thorens
W

Wards 0054

レーザーディスクのセットアップコード SETUP CODES FOR LASER DISC SETUP-CODES FÜR LASER-DISCS CODES DE REGLAGE POUR DISQUE LASER REGOLAZIONE CODICI PER DISCHI LASER AJUSTAR CÓDIGOS PARA DISCOS LÁSER INSTELCODES VOOR LASERDISC INSTÄLLNINGSKODER FÖR LASER DISC-SPELARE 鐳射影碟播放機設置代碼 镭射影碟播放机设置代码

C
Carver
D Denon
Marantz
N NAD
O Optimus
P Phillips .0091 Pioneer .0086
S Salora
T Telefunken

DBS のセットアップコート SETUP CODES FOR DBS SETUP-CODES FÜR DIGITALEN SENDESATELLITEN-TUNER CODES DE REGLAGE POUR TUNER D'ÉMISSION PAR SATELLITE REGOLAZIONE CODICI PER SINTONIZZATORE VIA SATELLITE PER TRASMISSIONI DIGITALI AJUSTAR CÓDIGOS PARA SINTONIZADOR DE EMISIONES DIGITALES POR SATÉLITE INSTELCODES VOOR DIGITALE SATELLIETONTVANGER INSTÄLLNINGSKODER FÖR SATELLITMOTTAGARE 數碼廣播衛星設置代碼 数码广播卫星设置代码 Fuba 0423 G ABsat. 0150 Alba 0482 AlphaStar. 0799 Galaxis 0890, 1138 Amstrad. 0874 General Instrument 0896 Astro 0200 Atsat 1327 Avalon 0423 В Hirschmann 0200, 0423 Blaupunkt 0200 Hitachi 0846, 0482 British Sky Broadcasting 0874, 1202 Hughes Network Systems . . 1169, 0776, 1776 Humax 0890, 1203 Canal Digital 0880 Canal Satellite 0880 InVideo 0898 Canal+.....0880 Chaparral 0243 Connexions 0423 Crossdigital 1136 Kathrein 0150, 0200, 0227, 0276, 0685, Cyrus......0227 1248 Kreiselmeyer 0200 D L DNT.....0227, 0423 Digenius 0326 DirecTV 0419, 0593, 0666, 1169, 0274, 0776, 1776, 0751, 0846, 1883, Manhattan 0482, 1044, 1110 Marantz 0227 1103, 1136 MediaSat 0880 Dish Network System 1032, 0802 Memorex 0751 DishPro 1032, 0802 Metronic 0111 Dream Multimedia 1264 Motorola..... 0896 Myryad 0227 0880, 0898, 1113 Next Level 0896 Engel 1044 Nokia 0482, 0750, 0778, 1154, 1250, Expressvu 0802 0 FTE 0890 Orbitech 1127 Fracarro 0898

P Pace 0482, 0874, 1202, 1350 Panasonic 0274, 0728, 0874, 1347 Panda 0482 Paysat 0751 Philips 1169, 0776, 1776, 0751, 1103, 0749, 0160, 0227, 0482, 0880	テレビのセットアップコード SETUP CODES FOR TELEVISION SETUP-CODES FÜR FERNSEHGERÄTE CODES DE REGLAGE POUR TELEVISION REGOLAZIONE CODICI PER TELEVISIONE AJUSTAR CÓDIGOS PARA TELEVISIÓN INSTELCODES VOOR TELEVISIE
Pioneer 0880 Promax 0482 Proscan 0419, 0593	INSTÄLLNINGSKODER FÖR TV-APPARATER 電視機設置代碼
R	电视机设置代码
RCA0419, 0593, 0882, 0170	
RFT	A
RadioShack	AGB
Radiola 0227	0205, 0036, 0119, 0135
Radix	ASA0131
S	AWA0036
SKY 0883, 0874, 1202	Acura
SM Electronic 1227	Addison
Sabre0482	Admiral0120, 0490, 0190
Sagem	Advent
Samsung	Aiko
Satstation	0388, 0543
Schwaiger	Akura
Seemann0423	Alba
Siemens 0200	America Action0207
Sony	Ampro
Star Choice	Amstrad
Strong	0460, 0543 Anam
T	Anam National
TPS	Anitech
Tantec	Apex Digital
TechniSat	Audiosonic
Thomson	Audiovox
Topfield	В
Toshiba	Bang & Olufsen
U	Basic Line
UltimateTV 0419, 0666	Baur
Uniden	Baysonic
Universum0200	Beaumark
V	Beko
Ventana	Beon
	Blaupunkt0222
W	Blue Sky
Wisi	Bondstec
X	Bradford
XSat0150	Brandt
Z	Broksonic
Zehnder	1064
Zenith	
	C
	CCE0064 CGE
	CTC0274
	010 11111111111111111111111111111111111

CXC	0207	F	
Candle		•	0064, 0100, 0136, 0265, 0314,
Carnivale		r organor	0362, 0587
Carver	. 0081, 0197	Fidelity	· ·
Cascade	. 0036	Finlandia	
Cathay	. 0064		0064, 0131, 0132, 0373, 0543
Celebrity	. 0027	Firstar	0263, 0036
Celera	. 0792	Firstline	
Centurion	. 0064	Fisher	0181, 0131, 0235, 0397
Changhong	. 0792	Flint	0482
Ching Tai	. 0036, 0119	Formenti	0064, 0347
Chun Yun		Fortress	0120
Chung Hsin		Frontech	
Cimline		Fujitsu	
Cineral		Funai	
Citizen		Futuretech	0207
Clarion		G	
Clarivox		_	0074, 0078, 0478, 0207, 0057,
Clatronic			0205, 1481, 0119,0587, 1174,
Condor			1374
Contac		GEC	
Contec		Gateway	
Craig		Geloso	
•	. 0207, 0036, 0064, 0397, 0445	Genexxa	0190
	. 0074, 0081, 0181, 0478, 0120,	Gibralter	0044, 0057
Curtis Matries	0087, 0729, 0057, 0172, 0193,	GoldStar	0181, 0057, 0205, 0064, 0136,
	1174, 1374		0404
_	1171, 1071	Goodmans	0064, 0398, 0401, 0661
D		Gorenje	0397
Daewoo	. 0181, 0478, 0207, 0057, 0205,	Gradiente	0080, 0197
	1688, 0036, 0064, 0119, 0135,	Graetz	0190, 0388
	0197, 0401, 0650, 0661	Granada	0064, 0235, 0366, 0543
Dansai		Grandin	0637
Dayton		Grundig	0064, 0222, 0514, 0583, 0614
De Graaf	•	Grunpy	0207
Decca	•	Н	
Denon		HCM	0036. 0439
Digatron		Hallmark	· ·
Dumont	•	Hankook	
Dwin			0064, 0347, 0388, 0455, 0583
DWIII	. 0747, 0001	Hantarex	0543
E		Harman/Kardon	0081
ECE		Harvard	0207
Elbe		Havermy	0120
Electroband		Hello Kitty	
Elin	•	Hinari	
Elite		Hisawa	
Elta		Hitachi	0057, 0205, 1172, 0172, 1283,
Emerson	. 0181, 0263, 0490, 0207, 0205,		0036, 0119, 0132, 0136, 0190,
Facilities	0388, 0650		0252, 0383, 0508, 0575, 0605
Envision		Hua Tun	
Erres		Huanyu	
Ether		Hypson	0004, 0291
Etron	•	1	
Europhon		ICE	0291, 0398
za.opilon	. 55.5	ITS	0398
		ITT	
		Imperial	0274, 0397, 0445

Indiana	Microstar
Infinity	Midland
Ingelen 0190	Minerva
Inno Hit	Minoka
Innova 0064	Mitsubishi
Inteq	0177, 1277, 0057, 0205, 0135,
Interfunk	0539, 0863
Intervision	Mivar
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Motorola0120
J	
JBL	Multitech
JCB0027	Myryad
	NI .
JVC 0490, 0080, 0398, 0680, 0710	N
Jean 0183, 0078, 0263, 0036, 0119	NAD
Jensen 0788	NEC
17	0036, 0197, 0482, 0524, 1731
K	NEI
KEC	NTC0119
KTV 0207, 0057	
Kaisui	Neckermann
	Netsat
Kapsch	Newave
Karcher	Nikkai
Kathrein 0583	Nikko
Kendo	
Kenwood	Nokia
Kneissel	Norcent
·	Nordmende
Kolin	
Korpel	0
Koyoda	Oceanic
	Onwa
L	Optimus
L&S Electronic 0835	Optonica0120
LG	
0741	Orion
	Osaki
LXI	Otto Versand
Leyco	
Liesenk & Tter	P
Loewe	Palladium
Luxor	Panama
	Panasonic
M	
M Electronic	0677, 1437
0190, 0314, 0373, 0401, 0507	Pathe Cinema0265, 0347
MGA	Pausa
	Penney
MTC	0205, 1374
Magnadyne 0274, 0543	Perdio0347
Magnafon 0543	Philco
Magnavox	
	0172, 1688, 0064, 0274
Manestn 0291 03/L/	
Manesth	Philips
Marantz	
Marantz	Philips
Marantz 0081, 0057, 0064, 0583 Mark 0064 Matsui 0036, 0064, 0235, 0398, 0514, 0543 Matsushita 0277, 0677	Philips
Marantz. 0081, 0057, 0064, 0583 Mark. 0064 Matsui. 0036, 0064, 0235, 0398, 0514, 0543 Matsushita 0277, 0677 Mediator. 0064	Philips
Marantz. 0081, 0057, 0064, 0583 Mark. 0064 Matsui. 0036, 0064, 0235, 0398, 0514, 0543 Matsushita 0277, 0677 Mediator. 0064 Medion. 0695, 0835, 1064	Philips
Marantz. 0081, 0057, 0064, 0583 Mark. 0064 Matsui. 0036, 0064, 0235, 0398, 0514, 0543 Matsushita 0277, 0677 Mediator. 0064 Medion. 0695, 0835, 1064 Megatron 0205, 0172	Philips
Marantz. 0081, 0057, 0064, 0583 Mark. 0064 Matsui. 0036, 0064, 0235, 0398, 0514, 0543 Matsushita 0277, 0677 Mediator. 0064 Medion. 0695, 0835, 1064	Philips
Marantz 0081, 0057, 0064, 0583 Mark 0064 Matsui 0036, 0064, 0235, 0398, 0514, 0543 Matsushita 0277, 0677 Mediator 0064 Medion 0695, 0835, 1064 Megatron 0205, 0172 Memorex 0181, 0277, 0490, 0177, 0205,	Philips
Marantz 0081, 0057, 0064, 0583 Mark 0064 Matsui 0036, 0064, 0235, 0398, 0514, 0543 Matsushita 0277, 0677 Mediator 0064 Medion 0695, 0835, 1064 Megatron 0205, 0172 Memorex 0181, 0277, 0490, 0177, 0205, 0036, 1064	Philips .0081, 0027, 0078, 0057, 0205, 1481, 0064, 0119, 0135, 0401, 0583, 0717 Phonola .0064 Pilot .0057 Pioneer .0193, 0136, 0190, 0314, 0706, 0787, 0893 Portland .0119 Prandoni-Prince .0543 Prima .0788 Prism .0078
Marantz 0081, 0057, 0064, 0583 Mark 0064 Matsui 0036, 0064, 0235, 0398, 0514, 0543 Matsushita 0277, 0677 Mediator 0064 Medion 0695, 0835, 1064 Megatron 0205, 0172 Memorex 0181, 0277, 0490, 0177, 0205,	Philips

Protech	Siemens
0695	Sinudyne 0543
Proton	Skantic 0383
Pulsar	Skygiant 0207
Q	Skyworth
Quasar0277, 0078, 0677	Solavox 0190
Quelle	Sonitron 0235
	Sonoko
R	Sonolor 0190, 0235
R-Line	Sontec 0064
RCA0074, 0027, 0057, 0205, 1474,	Sony
1481, 0117, 0119, 0706, 1074,	1678
1174, 1274, 1374, 1574	Soundesign
RFT	Soundwave
RadioShack	Sowa
Radiola	Squareview
Radiomarelli0543	Starlite
Realistic	Stern
Rediffusion	Supreme
Reoc	Sylvania
Revox	Symphonic
Roadstar	Synco
Runco	0119
Tranco	Sysline
S	
SBR0064	Т
SEG0291, 0695	T + A 0474
SEI0543	TCM
SKY	TMK 0205
SSS 0207	TNCi
Saba	TVS
Saccs	Tacico
Sagem	Tai Yi
Saisho	Tandy
Salora	Tashiko
Sambers	Tatung
Sampo	0036, 0064, 0543 Teac
0036, 0119, 0677, 1782	0482, 0695, 1064
Samsung	Tec
0205, 0036, 0064, 0117, 0119,	Technema
0291, 0397, 0583, 0614, 0645, 0793, 0841	Technics
Sansei	Techwood
Sansui	Teco
Sanyo	0291, 0680
0826	Teknika
Schaub Lorenz 0388	Telefunken 0729, 0136, 0289, 0362, 0652
Schneider	Telemeister
Scotch0205	Teletech
Scott	Tensai 0347
Sears	Tera
0198	Thomson
Seleco0190, 0286	Thorn
Semivox	Toshiba
Semp0183	0645, 0677, 0859, 1383, 1683,
Sharp0120, 0057, 0677	1731
Shen Ying	Triumph 0543
Sheng Chia 0120, 0263, 0036	Tuntex
Siarem0543	

U

V

 Videosat
 0274

 Vidikron
 0081

 Vidtech
 0205

 ViewSonic
 1782

 Vision
 0347

 Voxson
 0190

W

Waltham 0383

White Westinghouse 0490, 0064, 0347, 0650

γ

Yamaha 0057, 0796, 0860

Ζ

VCRのセットアップコード SETUP CODES FOR VCR SETUP-CODES FÜR VIDEOGERÄTE CODES DE REGLAGE POUR MAGNETOSCOPE REGOLAZIONE CODICI PER VIDEOREGISTRATORE (VCR) AJUSTAR CÓDIGOS PARA VCR INSTELCODES VOOR VIDEORECORDER INSTÄLLNINGSKODER FÖR VIDEOBANDSPELARE 錄像機設置代碼 录像机设置代码

Α

 Admiral
 .0075

 Adventura
 .0027

 Aiko
 .0305

В

 Baird
 .0027, 0131, 0068

 Basic Line
 .0099, 0305

 Beaumark
 .0267

 Bell & Howell
 .0131

 Blaupunkt
 .0253

 Brandt
 .0347

 Brandt Electronic
 .0068

C

 Calix
 .0064

 Canon
 .0062

 Carver
 .0108

 Cimline
 .0099

D	Interfunk0108
Daewoo	J
Dansai	JVC
De Graaf	Jensen
Decca0108, 0027	
Denon	K
Dual	KEC
Dumont	KLH
	Kenwood
E	Kodak
ESC	Kolin
Elcatech0099	Korpel
Electrohome	L
Electrophonic	LG
Emerson	LXI
0027, 0070, 0305, 1305, 1506	Lenco
	Leyco 0099
F	Lloyd's
Ferguson	Loewe 0064, 0108, 1589
Fidelity	Logik
Finlux	Luxor
Firstline	M
Fisher	M Electronic
Fuji	MEI 0062
Fujitsu	MGA 0267, 0070
Funai	MGN Technology 0267
G	MTC
GE	Magnasonic
1087	Magnavox
GEC0108	Magnin
Garrard	Marantz
General	Marta
Go Video	Matsui
GoldHand	Matsushita 0062
GoldStar	Medion
Goodmans	Memorex
Graetz	0267, 0027, 0131, 0334, 0375,
Granada	1264
Grandin	Memphis
Grundig	Metz
н	Mitsubishi
HCM	Motorola
HI-Q0074	Multitech
Hanseatic0064	Murphy
Harley Davidson 0027	Myryad 0108
Harman/Kardon 0108	N
Harwood	NAD 0131
Hinari	NEC
Hitachi	0068
Hughes Network Systems 0069	National 0253
Hypson	Neckermann 0108
I	Nesco 0099
ITT0267, 0131, 0068	Newave
ITV	Nikko
Imperial	Noblex 0267

Notis. 0257, 0131, 0088		
Oceanic 0027, 0688 Sanyo .0074, 0267, 0131 Oceanic 0027, 0688 Sawlle .0379 Okano .0342, 0375 Schaub Lorenz .0027, 0131, 0068 Opmous .0064, 0075, 0311, 0459 Schaub Lorenz .0027, 0131, 0069 Orion .0211, 0375, 0379, 1506 .0062, 0064, 0074, 0027, 0099 .0062, 0064, 0074, 0027, 0099 Otto Versand .0108 .0064, 0068, 0099 .0072, 0069, 0072 Palladium .0064, 0068, 0099 .0072, 0069, 0072, 0069, 0072 .0072, 0089, 0072, 0089, 0072 Pathe Marconi .0068 .0062, 0052, 0252, 0253, 0643, 1062, 1589 .0064, 0073, 0084, 0073, 0084 Petnax .0069 .0062, 0064, 0267, 0069, 1062, 1589 .0064, 0064, 0073, 0084 Pertax .0069 .0069 .0064, 0069, 0064, 0072, 0069, 0062, 0064, 0072, 0069, 0062, 0062, 0064, 0072, 0069, 0062, 0062, 0062, 0062, 0062, 0064, 0062, 0064, 0066, 0062 .0064 Philips .0062, 0064, 0064, 0064, 0064 .0064 .0064 Pilore .0064 .0064 .0064 Pilore .0108 .0064 .0064 Portar		Sanky
Oceanic 0027	Nordmende 0068, 0347	Sansui
Oceanic .0027 .0088 Saville .0374 .0077 .0088 Saville .0027 .0131 .0088 .0097 .0082 .0253 .0097 .0098 .0097 .0098 .0098 .0098 .0098 .0098 .0098 .0098 .0098 .0098 .0098 .0098 .0099 .0072 .0099 .0072 .0098 .0099	0	Sanyo
Okano	-	Saville
Olymous		Schaub Lorenz
Optimus		Schneider0108, 0027, 0099
Optimus	• •	
Orion		Sears
Claskit 0064 0027 0099 Seleco 0068 Claskit Claskit		
Semp		
Pailadium	Otto Versand0108	
Palladium. 0.064, 0.068, 0.099 Shintom 0.131, 0.099	P	·
Panasonic 0.062	<u>-</u>	
Pathe Marconi 0.068	·	
Pathe Marconi 0.068 Silva 0.064 Penney 0.062 0.064 0.267 0.069 1.062 Pentax 0.069 Sonic Blue 0.641 0.643 Pertio 0.027 Sontec 0.064 Philico 0.062 Sony 0.062 0.059 0.060 0.027 Philico 0.062 Sony 0.062 0.059 0.060 0.027 Philico 0.061 This 0.062 This 0.062 Philips 0.062 0.108 0.645 1.108 1.259 Phonola 0.108 Sunkai 0.375 Pilot 0.064 Sunstar 0.027 Pioneer 0.108 0.069 0.094 Sunkai 0.027 Pioneer 0.108 0.069 0.094 Sylvania 0.062 0.108 0.027 Proline 0.027 Tolline 0.027 Proline 0.027 Tolline 0.027 Proscan 0.087 1.087 TMK 0.267 Protec 0.099 Tandy 0.027 1.31 Pulsar 0.066 Tashiko 0.064 0.027 Pye 0.108 Tashiko 0.064 0.027 Qualar 0.062 1.062 Technics 0.062 0.068 0.050 0.068 Qualar 0.062 1.062 Technics 0.062 0.064 0.075 Quelle 0.108 Teco 0.062 0.064 0.075 RCA 0.087 0.062 0.267 0.069 0.834 Teleavia 0.068 RCA 0.087 0.062 0.267 0.069 0.834 Teleavia 0.068 Radiox 0.064 0.075 0.074 0.027 Tensai 0.027 Radios 0.064 0.064 0.075 0.074 0.027 Tensai 0.027 0.068 0.068 Realestic 0.062 0.064 0.075 0.074 0.027 Tensai 0.027 0.068 0.068 Realestic 0.066 0.062 0.064 0.075 0.074 0.072 0.064 0.066 0.064 0.066 0.06		-
Penney		
Pentax		
Pentax	•	
Perdio 0027		· ·
Philico 0062		·
Philips		
Phonola 0 108		·
Pilot	·	1=00
Pioneer 0108, 0069, 0094 Suntronic .0027 Polk Audio 0108 Sylvania .0062, 0108, 0027, 0070, 1808 Profitronic 0267 Symphonic .0027 Proline .0027 T Proscan .0087, 1087 TMK .0267 Protec .0099 Tandy .0027, 0131 Pulsar .0066 Tashiko .0064, 0027 Pye .0108 Tatung .0108, 0072, 0027, 0094, 0068 Quasar .0062, 1062 Technics .0062, 0253 Quelle .0108 Teco .0062, 0064, 0075, 0068 RCA .0087, 0062, 0267, 0069, 0834, 1062, 1087 Teleavia .0068 RAGIoShack .0027 Teleavia .0068 Radiola .0108 Teleavia .0068 Radiola .0108 Teleavia .0068 Radix .0064 Thomas .0027 Radix .0064 Thomas .0027 Realistic .0062, 0064, 0075, 0074, 0027, 0027 <td< td=""><td></td><td></td></td<>		
Polk Audio		
Profitronic 0267 Symphonic .0027 Proline .0027 T Proscan .0087, 1087 TMK .0267 Protec .0099 Tandy .0027, 0131 Pulsar .0066 Tanty .0064, 0027 Pye .0108 Tatung .018, 0072, 0027, 0094, 0068 Quasar .0062, 1062 Technics .0062, 0253 Quelle .0108 Technics .0062, 0253 Quelle .0108 Technics .0062, 0263, 0334, 0669 RCA .0087, 0062, 0267, 0069, 0834, 16e2 Technics .0062, 0064, 0075, 0068 RCA .0087, 0062, 0267, 0069, 0834, 16e2 Televinka .0062, 0064, 0027 RadioShack .0027 Telesia .0068, 0347 RadioShack .0027 Tensai .0027 Radiola .0108 Tensai .0027 Radiola .0108 Tensai .0027 Radiola .0108 .0064 .0064, 0064 Realistic .0062, 0064, 0075, 0		
Proline. 0027 T Proscan 0087, 1087 TMK .0267 Protec 0099 Tandy .0027, 0131 Pulsar 0066 Tashiko .0064, 0027 Pye 0108 Tashiko .0064, 0027 Tatung .0108, 0072, 0027, 0094, 0068 .0062, 0068, 0305, 0334, 0669 Quasar. .0062, 1062 Technics .0062, 0253 Quelle .0108 Technics .0062, 0264, 0075, 0068 R Teknika .0062, 0064, 0075, 0068 Teknika .0062, 0064, 0027 RadioShack .0027 Teleavia .0068 .047 RadioShack .0027 Tensai .0097 .0068, 0347 .0068, 0347 .0064		·
Proscan 0087, 1087 TMK .0267 Protec .0099 Tandy .0027, 0131 Pulsar .0066 Tashiko .0064, 0027 Pye .0108 Tatung .0108, 0072, 0027, 0094, 0068 Quasar. .0062, 1062 Technics .0062, 0253 Quelle .0108 Teco .0062, 0064, 0075, 0068 R Technika .0062, 0064, 0075, 0068 RCA. .0087, 0062, 0267, 0069, 0834, 1062, 1087 Telerfunken .0068, 0347 RadioShack .0027 Tensai .0099 RadioShack .0027 Tensai .0099 Radiola .0108 Tensai .0027 Radiola .0108 Tensai .0027 Radiola .0064 Thomas .0027 Radiola .0108 Thomas .0027 Radiola .0108 Thomas .0027 Radiola .0108 Thomas .0027 Radiola .0108 Thomas .0084		Symphome
Protec. 0099		Т
Pulsar 0066 Tashiko 0027 Pye 0108 Tashiko 0064, 0227 Quesar 0062, 1062 Teac 0027, 0068, 0305, 0334, 0669 Quelle 0108 Technics .0062, 0253 Quelle 0108 Teco .0062, 0064, 0075, 0068 R Teknika .0062, 0064, 0027 RCA .087, 0062, 0267, 0069, 0834, 1062, 1087 Teleavia .0068 RCA .0087, 0062, 0267, 0069, 0834, 1062, 1087 Teleavia .0068, 0347 RadioShack .0027 Tensal .0099 RadioShack .0027 Tensal .0099 RadioShack .0027 Tensal .0027 RadioShack .0027 Tensal .0027 RadioShack .0027 Tensal .0027 RadioShack .0027 .0064 .0027 RadioShack .0027 .0064 .0027 RadioShack .0064 .0064 .0027 RadioShack .0064 .0064 .00		TMK
Pye		Tandy
Q Teac .0027, 0068, 0305, 0334, 0669 Quasar. .0062, 1062 Technics .0062, 0253 Quelle .0108 Teco .0062, 0064, 0075, 0068 R Teco .0062, 0064, 0027 Teknika .0062, 0064, 0027 RadioShack .0027 Teleavia .0068 .0047 Radiola .0108 Telefunken .0068, 0347 Radioshack .0027 Tensai .0027 Radix .0064 Thomas .0027 Radix .0064 Thomas .0027 Randex .0064 Thorn .0131, 0068 Realistic .0062, 0064, 0075, 0074, 0027, 0074, 0027, 0074, 0027 .00645, 0663 .0068, 0072, 0094, 0070, 0068, 0072, 0094, 0070, 0068, 0072, 0094, 0070, 0068, 0072, 0094, 0070, 0068, 0072, 0094, 0070, 0068, 0072, 0094, 0070, 0068, 0072, 0094, 0070, 0064, 0070, 0064, 0070, 0064, 0072, 0094, 0064, 0072, 0094, 0064, 0072, 0094, 0064, 0072, 0094, 0064, 0072, 0094, 0068, 0072, 0094, 0068, 0072, 0094, 0068, 0072, 0094, 0068, 0072, 0072, 0094, 00		Tashiko
Ouesar. 0062, 1062 Technics 0062, 0253 Quelle 0108 Teco 0062, 0064, 0075, 0068 R Teco 0062, 0064, 0027 RCA. 0087, 0062, 0267, 0069, 0834, 1062, 1087 Teleavia. 0068, 0347 RadioShack 0027 Tensai. 0027 Radioile 0108 Thomas. 0027 Radix. 0064 Thomas. 0027 React. 0062, 0064, 0075, 0074, 0027, 0074, 0027, 0087, 0087, 0094, 0068, 0347 Thorn. 0131, 0068 React. 0375 Toshiba. 0108, 0072, 0094, 0070, 0068, 0872 0072 Rex. 0068 Uher. 0267 0064, 0267 Sem. 0108 Vector. 0072 SEG. 0267	Pye	Tatung
Ouesar. 0062, 1062 Technics 0062, 0253 Quelle 0108 Teco 0062, 0064, 0075, 0068 R Teco 0062, 0064, 0027 RCA. 0087, 0062, 0267, 0069, 0834, 1062, 1087 Teleavia. 0068, 0347 RadioShack 0027 Tensai. 0027 Radioile 0108 Thomas. 0027 Radix. 0064 Thomas. 0027 React. 0062, 0064, 0075, 0074, 0027, 0074, 0027, 0087, 0087, 0094, 0068, 0347 Thorn. 0131, 0068 React. 0375 Toshiba. 0108, 0072, 0094, 0070, 0068, 0872 0072 Rex. 0068 Uher. 0267 0064, 0267 Sem. 0108 Vector. 0072 SEG. 0267	0	•
Quelle 0108 Teco .0062, 0064, 0075, 0068 R Teknika .0062, 0064, 0027 RCA .0087, 0062, 0267, 0069, 0834, 1062, 1087 Teleavia .0068, 0347 RadioShack .0027 Tensai .0027 Radiola .0108 Thomas .0027 Radix .0064 .0064 Thomson .0087, 0094, 0068, 0347 Realistic .0062, 0064, 0075, 0074, 0027, 0131 .0087, 0094, 0068 .0087, 0094, 0068, 0347 RepolayTV .0641, 0643 Totevision .0064, 0267 .0064, 0267 Rex .0068 .0064, 0267, 0099, 0305 Uher .0267 S .0064 .0267 Universum .0064, 0108, 0267, 0027 SEG .0267 Vector .0072 STS .0069 Victor .0094, 0068 Saba .0068, 0347 Video Concepts .0072 Salora .0070 Video Concepts .0072 Salora .0064, 0075 Video Sonic .0267	_	
R Teknika .0062, 0064, 0027 RCA. 0087, 0062, 0267, 0069, 0834, 1062, 1087 Teleavia .0068 0347 RadioShack 0027 Tenosal .0099 Radiola 0108 Thomas .0027 Radix 0064 Thomas .0027 Randex 0064 Thomson .0087, 0094, 0068, 0347 Realistic 0062, 0064, 0075, 0074, 0027, 11vo .0645, 0663 Reoc 0375 Toshiba .0108, 0072, 0094, 0070, 0068, 0872 ReplayTV 0641, 0643 Totevision .0064, 0267 Rex 0068 Roadstar 0064, 0267, 0099, 0305 U Runco 0066 Uher .0267 SBR 0108 Universum .0064, 0108, 0267, 0027 SEG 0267 V SEI 0108 Vector .0072 STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Video concepts .0064 Sampo 0064, 0075 Videosonic <td< td=""><td></td><td></td></td<>		
RCA. 0087, 0062, 0267, 0069, 0834, 1062, 1087 Teleavia. 0068 RadioShack 0027 Tenosal 0027 Radiola 0108 Thomas 0027 Radix 0064 Thomson 0087, 0094, 0068, 0347 Realistic 0062, 0064, 0075, 0074, 0027, 1700 0645, 0663 Resc 0375 ReplayTV 0641, 0643 Rex 0068 Roadstar 0064, 0267, 0099, 0305 Runco 0066 Roadstar 0066 Resc 0267 SBR 0108 SEG 0267 SEI 0108 STS 0069 Saba 0068, 0347 Sampo. 0064, 0075 Sampo. 0064, 0075 Video Concepts 0064 Sampo. 0064, 0075 Video Concepts 0064 Sampo. 0064, 0075 Video Sonic 0267 Video Concepts 0064 Signary 0064, 0075 Video Sonic 0267 Video Sonic 0267 Video Sonic 0267		
RCA. 0087, 0062, 0267, 0069, 0834, 1062, 1087 Telefunken .0068, 0347 RadioShack 0027 Tenosal .0099 Radiola 0108 Thomas .0027 Radix 0064 Thomas .0027 Randex 0064 Thomson .0087, 0094, 0068, 0347 Realistic 0062, 0064, 0075, 0074, 0027, 074, 0027 Thorn .0131, 0068 Reoc 0375 .0108, 0072, 0094, 0070, 0068, 0872 ReplayTV 0641, 0643 Totevision .0064, 0267 Rex 0068 .0068 .0064, 0267 Runco 0066 Uher .0267 SBR 0108 Universum .0064, 0108, 0267, 0027 SEG 0267 V SEI 0108 Vector .0072 STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Video Concepts .0064 Sampo 0064, 0075 Videosonic .0267		
Tenosal 0.0099	RCA0087, 0062, 0267, 0069, 0834,	
RadioShack 0027 Tensai .0027 Radiola 0108 Thomas .0027 Radix 0064 Thomson .0087, 0094, 0068, 0347 Rendex 0062, 0064, 0075, 0074, 0027, 10027, 0031, 0068 Thorn .0131, 0068 Realistic 0062, 0064, 0075, 0074, 0027, 10027, 0064, 0064, 0068, 0072, 0094, 0070, 0068, 0872 Thorn .0131, 0068 Reoc 0375 0872 0872 ReplayTV 0641, 0643 Totevision .0064, 0267 Rex 0068 0064, 0267 .0064, 0267 Runco 0066 Uher .0267 SBR 0108 Universum .0064, 0108, 0267, 0027 SEG 0267 V SEI 0108 Vector .0072 STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Video Concepts .0064 Sampo 0064, 0075 Video Sonic .0267	•	
Radiola 0108 Thomas .0027 Radix 0064 Thomson .0087, 0094, 0068, 0347 Randex 0064 Thorn .0131, 0068 Realistic 0062, 0064, 0075, 0074, 0027, 0131 Tivo .0645, 0663 Reoc 0375 Toshiba .0108, 0072, 0094, 0070, 0068, 0872 ReplayTV 0641, 0643 Totevision .0064, 0267 Rex 0068 Uher .0267 Runco 0066 Uher .0267 SBR 0108 Universum .0064, 0108, 0267, 0027 SEG 0267 V SEI 0108 Vector .0072 STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videomagic .0064 Sampo 0064, 0075 Videosonic .0267	RadioShack 0027	
Radix 0064 Thomson .0087, 0094, 0068, 0347 Randex 0064 Thorn .0131, 0068 Realistic. 0062, 0064, 0075, 0074, 0027, 0131 Thorn .0131, 0068 Reoc 0375 Toshiba .0108, 0072, 0094, 0070, 0068, 0872 ReplayTV 0641, 0643 Totevision .0064, 0267 Rex 0068 Uher .0267 Runco 0066 Uher .0267 SBR 0108 Unitech .0267 SEG 0267 V SEI 0108 Vector .0072 STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videomagic .0064 Sampo 0064, 0075 Videosonic .0267	Radiola 0108	
Randex 0064 Thorn .0131, 0068 Realistic. 0062, 0064, 0075, 0074, 0027, 0074, 0027, 00645, 0663 Tivo. .0645, 0663 Reoc. 0375 .0108, 0072, 0094, 0070, 0068, 0872 ReplayTV. .0641, 0643 Totevision .0064, 0267 Rex. .0068 .0064, 0267, 0099, 0305 U Runco. .0066 Uher. .0267 SBR. .0108 Universum .0064, 0108, 0267, 0027 SEG. .0267 V STS. .0069 Victor .0072 Saba .0068, 0347 Video Concepts .0072 Salora .0070 Videosonic .0064 Sampo. .0064, 0075 Videosonic .0267		
Realistic. 0062, 0064, 0075, 0074, 0027, 0131 Tivo. .0645, 0663 0872 Reoc. 0375 Toshiba. .0108, 0072, 0094, 0070, 0068, 0872 ReplayTV. 0641, 0643 Totevision. .0064, 0267 Rex. 0068 U .0064, 0267 Runco. 0066 Uher. .0267 SBR. 0108 Universum. .0064, 0108, 0267, 0027 SEG. 0267 V SEI. 0108 Vector. .0072 STS. 0069 Victor. .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videosonic. .0267 Sampo. 0064, 0075 Videosonic. .0267		
Name	Realistic	
Reoc 0375 0872 ReplayTV 0641, 0643 Totevision .0064, 0267 Rex 0068 U Roadstar 0064, 0267, 0099, 0305 U Runco 0066 Uher .0267 SBR 0108 Universum .0064, 0108, 0267, 0027 SEG 0267 V SEI 0108 Vector .0072 STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videomagic .0064 Sampo 0064, 0075 Videosonic .0267		
ReplayTV. 0641, 0643 Totevision .0064, 0267 Rex 0068 U Roadstar 0064, 0267, 0099, 0305 U Runco 0066 Uher .0267 Unitech .0267 Universum .0064, 0108, 0267, 0027 SEG 0267 V SEI. 0108 Vector .0072 STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videomagic .0064 Sampo 0064, 0075 Videosonic .0267	Reoc	
Rex 0068 U Roadstar 0064, 0267, 0099, 0305 U Runco 0066 Uher .0267 Unitech .0267 Universum .0064, 0108, 0267, 0027 SBR 0108 V V SEI 0108 Vector .0072 STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videomagic .0064 Sampo 0064, 0075 Videosonic .0267	ReplayTV 0641, 0643	
Runco 0066 Uher .0267 S Unitech .0267 SBR 0108 V SEG 0267 V STS 0069 Victor .0072 STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videomagic .0064 Sampo 0064, 0075 Videosonic .0267		
Runco 0066 Uher .0267 S Unitech .0267 Universum .0064, 0108, 0267, 0027 V V SEI 0108 Vector .0072 STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videomagic .0064 Sampo 0064, 0075 Videosonic .0267	Roadstar	-
SBR 0108 SEG 0267 SEI. 0108 Vector .0072 STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videomagic .0064 Sampo. 0064, 0075 Videosonic .0267		Uher
SBR 0108 SEG 0267 V SEI. 0108 Vector. .0072 STS 0069 Victor. .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videomagic. .0064 Sampo. 0064, 0075 Videosonic. .0267	c	Unitech0267
SEG 0267 V SEI. 0108 Vector. .0072 STS 0069 Victor. .0094, 0068 Saba 0068, 0347 Video Concepts. .0072 Salora 0070 Videomagic. .0064 Sampo. 0064, 0075 Videosonic. .0267		Universum
SEI. 0108 Vector. .0072 STS 0069 Victor. .0094, 0068 Saba 0068, 0347 Video Concepts. .0072 Salora 0070 Videomagic. .0064 Sampo. 0064, 0075 Videosonic. .0267		V
STS 0069 Victor .0094, 0068 Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videomagic .0064 Sampo 0064, 0075 Videosonic .0267		
Saba 0068, 0347 Video Concepts .0072 Salora 0070 Videomagic .0064 Sampo 0064, 0075 Videosonic .0267		
Salora 0070 Videomagic		
Sampo		·
Samsung	•	
	Samsung0267, 0072, 0459	viliali1

w 0267, 0027, 0069, 0099 White Westinghouse 0099 X XR-1000......0062, 0027, 0099 Υ Yamaha 0068

Z

デジタルビデオディスクのセットアップコ-SETUP CODES FOR DIGITAL VIDEO DISC SETUP-CODES FÜR DIGITALEN VIDEODISC CODES DE REGLAGE POUR VIDEODISQUE NUMERIQUE REGOLAZIONE CODICI PER VIDEODISCHI DIGITALI AJUSTAR CÓDIGOS PARA DISCOS DE VIDEO DIGITALI INSTELCODES VOOR DIGITAL VIDEODISC INSTÄLLNINGSKODER FÖR DIGITAL VIDEO DISC 數碼視頻碟設備代碼

数码视频碟设备代码

Acoustic Solutions 0757 Alba 0744 Amstrad 0740

Apex Digital 0699, 0744, 0782, 0821, 0823, 0857, 1127

Blaupunkt 0744 Blue Parade 0598 Bush 0740

C

В

Clatronic 0815 CyberHome 0741

DVD2000 0548 Dansai. 0797 Decca 0797 Digitrex 0699

F

Emerson 0618 Enterprise 0618

Fisher 0697

G

Go Video..... 0742 GoldStar 0768 Gradiente 0678 Greenhill 0744 Grundig..... 0566

Н

Hiteker 0699

J

K KLH Kenwood Koss	0517, 0561
LGLimit	
M Magnavox Marantz Memorex MiCO. Microsoft Mintek Mitsubishi Mustek N	0566 0858 0750 0549 0744 0548 0757
O Onkyo Oritron	0530
P Palsonic. Panasonic Philips Pioneer Polk Audio Proscan	0517, 0659, 1389 0530, 0566, 0673, 0881 0552, 0598, 0658, 0659 0566
Q Qwestar	
RCARotel	
S SM Electronic Samsung Sanyo Sharp Sherwood Shinsonic Slim Art Sony Sylvania	0600 0697 0657 0797 0560 0811 0560, 0891
T Tatung	0598, 0744 0517 0598 0549
U	0520

Urban Concepts 0530

X	
XBox	.0549
Y Yamaha	.0517, 0566, 0572
Z Zenith Zeus	

CD レコーダーのセットアップコード SETUP CODES FOR CD RECORDER SETUP-CODES FÜR CD-REKORDER CODES DE REGLAGE POUR ENREGISTREUR CD REGOLAZIONE CODICI REGISTRATORE CD AJUSTAR CÓDIGOS PARA GRABADOR CD INSTELCODES VOOR CD-RECORDER INSTÄLLNINGSKODER FÖR CD-BRÄNNARE CD録音機設備代碼 CD录音机设备代码

D Denon
К
Kenwood
Marantz
Philips

ミニディスクのセットアップコード SETUP CODES FOR MINIDISC (MD) SETUP-CODES FÜR MINIDISCS (MD) CODES DE REGLAGE POUR MINIDISC (MD) REGOLAZIONE CODICI PER MINIDISCO (MD) AJUSTAR CÓDIGOS PARA MINIDISCOS (MD) INSTELCODES VOOR MINIDISC (MD) INSTÄLLNINGSKODER FÖR MD-SPELARE 迷你磁碟播放機設置代碼

 D
 0000

 Denon
 0000

 K
 0708

 O
 000

 Onkyo
 0895

 S

迷你磁碟播放机设置代码

デジタルビデオディスク レコーダーのセットアップコード SETUP CODES FOR DIGITAL VIDEO DISC RECORDER SETUP-CODES FÜR DIGITALEN VIDEODISC-ROKORDER CODES DE REGLAGE POUR ENREGISTREUR DE VIDEODISQUE NUMERIQUE REGOLAZIONE CODICI PER REGISTRATORE DI VIDEODISCHI DIGITALI AJUSTAR CÓDIGOS PARA GRABADOR DE DISCOS DE VIDEO DIGITALI INSTELCODES VOOR DIGITAL VIDEODISC-RECORDER INSTÄLLNINGSKODER FÖR DIGITAL VIDEO DISC-

數碼視頻碟錄像機設備代碼 数码视频碟录像机设备代码

BRÄNNARE

 D
 0000

 P
 Panasonic
 0000

 T
 Toshiba
 0002